


RSS2TJ Firmware Update Utility


1. USB2.0 connection is suggested for update utility.
2. Unzip file to be .exe:




- (1) When the device is not connected:




- (2) If the device is detected:



- (3) After firmware is updated:



- (4) Re-power the device, the utility will detect Firmware version. If the firmware is updated, it will display:



It indicates the firmware update has been successfully executed.

- (5) Then place new PCBA, start the step (1).