



RCM4QJ Firmware Update & Utility


1. An USB 2.0 connection is recommended for updating firmware.
2. Decompress the firmware update file from *zip* to *.exe* format:




- (1) When the device is not connected, this will appear:




- (2) If the device is detected, select **YES** to continue:



- (3) After the firmware is updated, power off the device by selecting "Exit":



- (4) Power on the device and the Firmware Update Utility will detect its Firmware version. If the firmware is updated, this will appear:



This indicates that the firmware update has been successfully executed.

3. Execute the RAID MASTER (GUI) under Windows/Mac OS:



(1) Select **Advanced Mode** to begin.

(2) Select **Firmware Information** to continue.

(3) Select **Browse**, and then choose the firmware update file called:

RCM4QJ_ONNTO_09580922.bin

(4) Select **Update** to continue.

(5) After the firmware update is completed, power off the device. Then re-power on the device to check if the Firmware version states **V0.958[9/22]**. If so, this confirms that the firmware has been successfully updated.